



Shifter Alignment Tool

Effective: 5-FEB-2015

Unobtainium Supply Co. 523 Longley Rd Groton, MA 01450 978.448.2110 www.UnobtainiumSupply.com

Shifter Alignment Tool Instructions

This tool provides an easy way to precisely center the shifter stalk in the shift gate. The factory workshop manual method starts with 2"d gear adjustments, then in the last step the workshop manual directs you to make sure that the shifter shaft is centered in the gate, and adjust accordingly. We have found that setting the shifter by just doing the last step in this using the Shifter Alignment Tool, without the second gear step to be the most accurate way to get it right, and shifting is improved dramaticly.



- 1. NOTE: The Shifter Adjusting Tool is in two halves, with one end tapered, this is important
- 2. Place the two halves around the shifter stalk, with the tapered ends down, and place the clamp around both pieces in the groove provided.
- 3. With the shifter in the neutral position between 2nd & 3rd, push down firmly on the tool, and tighten the clamp down. A bit of "wiggling" as you tighten will insure that the tool is centered in the gate. This locks & centers the shifter stalk perfectly in the center of the neutral part of the gate.
- 4. Adjust the linkage at the transmission, just as you would normally. When the bolt hole lines up with the bushing, while in neutral, place the bolt in and tighten down, just as you would if using stock adjustment instructions, making sure that it is not too tight, as this will lock the shaft.
- 5. Remove the Shift Alignment Tool, and you are done.